


TACHOMETER SENDERS: USED TO MEASURE THE FLYWHEEL ROTATION SPEED. IP65 PROTECTION



MOD.	DESCRIPTION	L mm	L1 mm	THREAD	OUTPUT SIGNAL	FREQUENCY RANGE	CONNECTION	PART No.
KE10010	Magnetolectric tacho sender	100	80	M16x1.5	Sine wave	100-15000 Hz	Two wires	22531 HK
KE10004	Holzer tacho sender	80	70	M16x1.5	Square wave	0-20000 Hz	Three wires	22532 KK