| HALYARD PART No. | PART No. | SYSTEM DESCRIPTION |
|------------------|----------|---|
| H021247 | 23963 V | Single engine single station gauge with through hose sensor with 16 m cable |
| H021248 | 23964 X | Single engine single station gauge with removable through hose sensor with 16 m cable |
| H021249 | 23965 Z | Single engine dual station gauges with through hose sensors with 16 m cable |
| H021250 | 23966 B | Single engine dual station gauges with removable through hose sensors with 16 m cable |
| H021251 | 23967 D | Twin engine single station gauge with through hose sensor with 16 m cable |
| H021252 | 23968 F | Twin engine single station gauge with removable through hose sensor with 16 m cable |
| H021253 | 23969 H | Twin engine dual station gauges with through hose sensors with 16 m cable |
| H021254 | 23970 S | Twin engine dual station gauges with removable through hose sensors with 16 m cable |